

INSTRUCTION MANUAL
INTELLIGENT PRINTER
AD-8113



A&D MERCURY PTY. LTD.
32 DEW ST, THEBARTON, S.A., 5031

C O N T E N T S

1. INTRODUCTION	1
2. MAIN CHARACTERISTICS	1
3. PANEL DESCRIPTION	1
3-1 Front Panel	1
3-2 Rear Panel	1
4. DATA INPUT	2
4-1 Data Format	2
4-2 Command Signals	2
4-3 Data Input Pin Designation	2
4-4 Input Signal	3
4-5 Polarity Indication	3
4-6 Printer Output	4
4-7 Error Code	5
5. LOGIC SETTINGS	5
5-1 Decimal Point Setting	6
5-2 Logic Setting for "OVER"	6
5-3 Unit Selection	6
5-4 Printout of Maximum, Minimum and Average	6
5-5 Printout of Code	6
5-6 Print Line Space	7
5-7 Formula for Standard Deviation	7
5-8 Supplying the printing paper	7
5-9 Connection with the External Devices	8

1. INTRODUCTION


AD-8113 is an intelligent printer which can be used in connection with the A & D weighing indicators and electronic balances. It prints each input data together with date, code number, and Sequential number, and prints accumulated total, maximum, minimum and average of the data when total button is pushed.

2. MAIN CHARACTERISTICS


- 2-1 This journal printer uses the printing mechanism of the impact dot matrix method, and characters are printed in two colors-red and black.
- 2-2 This printer can print out Grandtotal and Subtotal of the data.
- 2-3 Maximum, minimum and average of the data are given.
- 2-4 Standard deviation of the accumulated data is given (Optional).

3. PANEL DESCRIPTION

3-1 Front Panel



3-2 Rear Panel



4. DATA INPUT

4-1 Data Format

- (1) Method Parallel BCD
- (2) Logic Positive (Data) Negative (Command)
- (3) Logic Level TTL Compatible, Fan-in 1.

High(1) +2.4 ~ +5V or Open
Low (0) 0 ~ 0.4V

4-2 Command Signals

Command signals such as Feed, Delete, Grand/Subtotal and Print can be given through the connector. The functions of these command signals are the same as the front keys and the pins from No. 26 to No. 30 are used.

The connections should be either by contact or by open collector, internal circuit of which is shown in Fig. 4-2




Fig. 4-2


4-3 Data Input Pin Designation

Connector 57-30500(DDK) will be supplied with AD-8113.

Pin No.	Signal	Pin No.	Signal
1	Logic Common	26	Command 1 (Feed)
2	1	27	Command 2 (Delete)
3	2	28	Command 3 ("Lo" for ON) ("Lo" for ON)
4	4	29	Command 4 (Subtotal)
5	8	30	Command 5 (Print)
6	1	31	
7	2	32	
8	4	33	
9	8	34	
10	1	35	
11	2	36	
12	4	37	
13	8	38	
14	1	39	
15	2	40	
16	4	41	
17	8	42	Polarity ("Lo" for minus)
18	1	43	
19	2	44	
20	4	45	
21	8	46	
22	1	47	Over ("Hi" for over indication)
23	2	48	
24	4	49	
25	8	50	

4-4 Input Signal

BCD codes through Data Input are interpreted as below.

BCD Codes	Interpreted as	Note
0 0 0 0	0	
0 0 0 1	1	
0 0 1 0	2	
0 0 1 1	3	
0 1 0 0	4	
0 1 0 1	5	
0 1 1 0	6	
0 1 1 1	7	
1 0 0 0	8	
1 0 0 1	9	
1 0 1 0	A	
1 0 1 1	B	
1 1 0 0	C	
1 1 0 1	D	
1 1 1 0	E	
1 1 1 1	Φ	

4-5 Polarity indication, over and commands are designated as shown in Table 4-5.

Table 4-5.

Signal	Polarity	Over	Command
Lo(0)	-		ON
Hi(1)	+	Over	OFF

"Over" logic can be set in negative logic by dip switch.

4-6 Printer Output

Printing Format

Printer will output the result in the following form.

Action	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	Notes																						
	No	Code																																												
PRINT	1	1	2	3	4	5	6											6	0	0	0	.	0	0	kg																					
PRINT	2	2	3	4	5	6	7											0	.	0	0																									
FEED																								Feed One Line *																						
PRINT	3	3	4	5	6	7	8											0	0	0	0	.	1	s	Red (Minus data)(1)																					
PRINT	3	3	4	5	6	7	8											0	0	5	2	.	7	8R	Red (Irrational data)																					
PRINT	3	3	4	5	6	7	8											E	0	.	0	OC																								
PRINT *	3	3	4	5	6	7	8											6	0	0	0	.	0	0																						
DELETE (2)	3	3	4	5	6	7	8																							Red																
PRINT	3	3	4	5	6	7	8											6	0	0	0	.	0	0																						
PRINT	4	4	5	6	7	8	9											6	0	0	0	.	0	0																						
PRINT	5	5	6	7	8	9	0											1	2	3	4	.	5	6																						
<hr/>																																														
SUBTOTAL	S. TOTAL 5										1										9	2	3	4	.	5	6																			
																MAX.	6										0	0	0	.	0	0														
																MIN.	0										.	0	0																	
																AVE.	3										8	4	6	.	9	1														
																*(3) S.D.	2										6	6	5	.	7	3														
																DATE	01.07.82																		Standard Deviation											

	No	Code																																												
PRINT	1	3	0	0	0	0	1											4	0	0	0	.	0	0	kg																					
PRINT	2	3	0	0	0	1	1											1	5	0	0	.	0	0																						
<hr/>																																														
																S. TOTAL	2										5										5	0	0	.	0	0				
																MAX.	4										0	0	0	.	0	0														
																MIN.	1										5	0	0	.	0	0														
																AVE.	2										7	5	0	.	0	0														
																S.D.	1										7	6	7	.	7	6														
																DATE	01.07. 82.																													

																G. TOTAL	7										2										2	1	7	6	.	1	2	kg		
																MAX.	6										0	0	0	.	0	0														
																MIN.	2										2	0	.	0	0															
																AVE.	3										1	6	8	.	0	2														
																S. D.	2										2	1	4	.	0	4														

Notes :*(1) Minus data are treated as error.

* (2) When "DELETE" button is pushed, the proceeding data are deleted after data to be deleted are printed out in red.

* (3) Standard deviation is optional.

4- Error Code

Printer prints in red color in case of the following errors and these error data are not included in data processing.

Error Code	Contents
C	Irrational data
R	Over range of data
S	Minus date


Table 4-6.

5. LOGIC SETTINGS

Before installation, logic settings must be done in order to suit the application.

Dip switches are located under the roll paper as shown in Fig. 5.

Note: Be sure to turn off power before any adjustment.



5-1 Decimal Point Setting

Decimal point is provided by a combination of dipswitches No.1, No.2 and No.3 of SW1 as below.

SW1			Decimal point position
No.1	No.2	No.3	
OFF	OFF	OFF	X X X X X X
ON	OFF	OFF	X X X X X.X
OFF	ON	OFF	X X X X.X X
ON	ON	OFF	X X X.X X X
OFF	OFF	ON	X.X X X X X
ON	OFF	ON	X.X X X X X
OFF	ON	ON	0.X X X X X X

5-2 Logic Setting for "OVER"

No.4 of SW 1 ON "Lo" for over indication
 OFF "Hi" for over indication

5-3 Unit Selection

Engineering unit of the data can be selected by a combination of No.5 and No.6 of SW1 as below.

SW1		Unit
No.5	No.6	
OFF	OFF	Space
ON	OFF	g
OFF	ON	kg
ON	ON	t

5-4 Printout of Maximum, Minimum and Average

Printout of maximum, minimum and average of data can be activated by No.7 of SW1.

No.7 of SW1 ON Print of Max., Min. and Ave. activated
 OFF Print of Max., Min. and Ave. deactivated.

5-5 Printout of Code

Print of Code can be activated or deactivated by No.8 of SW1.

No.8 of SW1 ON Print of Code activated.
 OFF Print of Code deactivated.

5-6 Print Line Space

Line space can be selected by No.1 of SW2.

<u>No.1 of SW2</u>	ON	Single space
	OFF	Double space

5-7 Formula for Standard Deviation


Two formula for standard deviation are available and can be selected by No.2 of SW2.

<u>No.2 of SW2</u>	ON	Population standard deviation
	OFF	Sample standard deviation

- Notes:
- (1) No.3 and No.4 of SW2 are used internally and should be kept OFF all the time.
 - (2) In normal use No.7 and No.8 SW1 should be ON.
 - (3) Turn off power always when you change dip switch settings.

5-8 Supplying the printing paper

Insert the printing paper to the inner part to the inner part of the slot (ii), then pushing the feed switch and then the printing paper will be taken into the printer then finally printing paper will output from under the printing head.



Finally, pass the paper under the cutter.


When you need to know about the characteristic of this printer, please refer to the chapter

5-9 Connection with the External Devices.

- a) Connect the connecting cable which will match for the each external device to the input device.
- b) Make the inside designation by dip switch (see the dip switch setting) for the each external device.
- c) Push the command switch.

By these operation, you can get the specified printing output. Use this printer under the full consideration within the regulated specification.

For example, Fig. 5-9. Show the connection with EX-2000A.



5-10 Finally, after connecting with the external device, put the power switch on, then LED lamp will be on and then set the printing paper. Finally, push the Feed switch until the print paper end appears from the Paper Outlet of the printer.

