

AD AD 4407

INITALISATION PROCEDURE

1. With the display off, press & hold the **NET/GROSS** key and press the **ON/OFF** key until the display shows **F 00**.
2. Press the **NET/GROSS** key display shows software version.
3. Press the **TARE** key twice display shows "init F"
4. Press the **CAL** key display shows "init C".
5. Press and hold the **NET/GROSS** key and then press the **ENTER** key, display shows "-----"and then "Cal C".
6. Press ON/OFF to turn the indicator off and exit the init procedure.