

MAINTENANCE MANUAL

Maintenance-FS-v.1.b 17.12.91 PH


DUAL RANGE BENCH SCALES



Table of Contents

| Section A • Dis-assembly | page | A • 1 |
|-------------------------------|------|--------|
| Removing the Scale Pod | | |
| Removing the Main Logic Board | page | A •5 |
| Removing the A-D Board | page | A • 6 |
| Removing the Power Board | page | A • 6 |
| Dis-assembling the Basework. | page | A •7 |
| Section B • Power Board | page | B • 1 |
| Circuit and Parts List | page | B • 2 |
| Description of Operation | page | B •3 |
| Typical Circuit Voltages | | |
| Section C • Analog Board | page | C • 1 |
| Circuit and Parts List | | |
| Description of Operation | page | C •3 |
| Section D • Main Board | page | D •1 |
| Circuit Diagram | page | D• 2 |
| Component Layout | page | D •3 |
| Component List | page | D •4 |
| Description of Operation | page | D •5 |
| Section E • Parts Locate | page | E • 1 |
| Battery Box Assembly | page | E •2 |
| FS-6kg Baseplate Assembly | page | E • 3 |
| FS-15kg Baseplate Assembly | page | E • 4 |
| FS-30kg Baseplate Assembly | page | E • 5 |
| Base Cover Assembly | page | E • 6 |
| Load Pan Assembly | page | E • 7 |
| Load Pan Assembly - Casting | page | E •8 |
| Baseplate Assembly - Casting | page | E • 9 |
| Cable Cover Assembly | page | E • 10 |
| Indicator Pod Assembly | page | E • 11 |
| Indicator Pod Parts List | page | E • 12 |
| Indicator Assembly | page | E • 13 |
| Indicator Parts List | page | E • 14 |

| Section F • Initialisation | page | F • 1 |
|-------------------------------------|------|-------|
| Characteristic Settings | page | F • 2 |
| The Characteristic Settings | page | F•4 |
| Section G · Recommended Spare Parts | page | G • 1 |
| Distributor Items | page | G •2 |
| Service Centre Items | page | G•3 |



FS Series • Section A


Dis-assembly



Dis-assembly of the FS Scale


X

Removing the Scale Pod




Switch OFF the mains power and unplug the AC adaptor.






■ Undo the battery compartment screws and remove the cover and batteries.






■ Remove the option board.






- ♠ Support the column during this step.
- Using the wrench provided with the scale undo and remove the two column supporting bolts.






Lay the column and pod face down on the bench.





Remove the 2 screws securing the Pod to the Column.






► Carefully pull the excess loadcell cable from the column and slide the column down the cable.




Securing Screws




▶ Remove the 2 screws securing the cable clamp plate.






Slide the plate down the loadcell cable and remove the grommet.





■ Remove the 6 screws securing the pod halves together.






Separate the 2 pod halves and unplug the loadcell connector from the p.c.b.


Removing the Main Logic Board





- Remove the A-D convertor plug.
- O 'B 'Type scale ONLY.
- ▶ Remove the Power Supply plug.






- Remove the 5 screws holding the board to the front panel.
- Lift out the board.


Removing the A-D Board





- O 'B 'Type scale ONLY.
- ▶ Remove the Power plug.






- Remove the 2 screws holding the board to the housing.
- Lift out the board.


Removing the Power Board






- O 'B 'Type scale ONLY.
- Remove the 2 screws holding the board to the housing.
- ▶ Free the cable and lift out the board.

Disassembling the Basework









▶ Hold the pan and carefully turn the scale right way up.







- ▶ Remove the pan and place to one side.
- Pan Remove the screw securing the overload stop.
 - Remove the overload stop & place to one side.
 - Remove the 3 screws securing the load plate to the loadcell.
 - Remove the load plate.




Premove the loadcell cable clip and screw.



- Support the column during this step.
- Using the wrench provided with the scale undo and remove the two column supporting bolts.
- Lay the column and pod onto the bench.




Undo the 2 cap head screws and feed the column support bracket through the slot in the base and up the loadcell cable.



▶ Invert the base and remove the 4 cap head screws securing the loadcell to the base.




- If necessary remove the pod from the column and free the loadcell cable. (See start of this section).
- Remove the loadcell by feeding the cable through the column and then through the slot in the basework.



FS Series • Section B

Power Board





Description of Operation

General

Raw D.C. voltage is supplied to this board via connector J6. This voltage will come from the internal batteries or from an external A.C. adaptor. The voltage will be about 8 Volts with the backlighting ON.

The circuit will, under the control of the microprocessor, generate an A.C. voltage, of about 90 Volts, to supply the back lighting element.


Q1 / Q2 act as a switch to control the voltage supplied to U1. This switch responds to the microprocessor command appearing at J5 - 3. Regulator U1 provides a 5 Volt D.C. supply to the Convertor CNV1. The convertor changes the input 5 Volt D.C. to an A.C. Voltage of about 90 Volts. This voltage is supplied via connector J5 - 3 to the Main Board PZ 2455 and thus to the backlighting element.



Typical Circuit Voltages


| From (+ Terminal) | To (- Terminal) | Voltage | Comments |
|----------------------|--------------------|----------------|--------------------|
| J6 - 3 | J6 - 1 | 8 Volts D.C. | Backlighting ON |
| J6 - 3 | J6 - 1 | 13 Volts D.C. | Backlighting OFF * |
| CNV1 - 1 | CNV1 - 2 | + 5 Volts D.C. | Backlighting ON |
| J5 - 1 | J5 - 2 | 90 Volts A.C. | Backlighting ON |

* A.C. Adaptor Supply



FS Series • Section C

Analog Board



Section C

page C • 2

*

Description of Operation


General

The Analog board connects to the loadcell and to the microprocessor on the main board. It's function is to compare the analog signal from the loadcell with a reference voltage and provide a Comparison signal to the microprocessor. The comparison is performed in the AMZ 38 hybrid convertor and is controlled by the input signals Z, 1st and 2nd generated by the microprocessor.

The board also has the A.C. adaptor socket J6 which connects the supply voltage, via the fuse FS1, to the main board.


Timing Diagram


| A/D Signal | Comments |
|------------|---|
| 1st | First integration signal - Inverts every 5 mS. |
| 2nd | Second integration signal - rises after the first fall and then stays high for a time proportional to the load cell output. |
| Comp | Comparator output signal - rises with 1st's rise and falls with 2nd's fall. |
| Z | Zero integration signal - used to check for offset voltage drift of the first stage OP-amp. This signal is normally low. If the weight is stable then the output will be high for 0.4 sec each 3.2 sec. |
| CAL sw | Normally High. If CAL switch is pressed then signal goes low. |
| CKI | A/D counter clock input - if 2nd is high then this is a 4MHz clock. |
| 1st | 5 mS 5 mS |
| 2nd | |
| Comp | |
| СКІ | |



FS Series • Section D

Main Board





COMPONENT LIST

| Circuit Reference | Part Number |
|-------------------|------------------|
| U1 | UC:MN158851-XWA |
| U2 | UC:RP93C46 |
| U3 | UC:HC00 |
| U 4 | UR:C2255H |
| Q1,Q2 | QT:A1015Y |
| Q3,Q4,Q5 | QT:BAIL4M |
| D1 to D13 | DI:ISS133 |
| D14 | DI:AL01Z |
| S1 to S12 | SK:TMI-01/0010 |
| XT | XT:EFO-FC4004A3 |
| BZ | ET:KBS-20DB-4P-0 |
| LCD | ED:FRD-10289 |
| EL | ED:ELD503-W * |
| R1,R5,R6 | RC:NAT100K |
| R2,R4 | RC:NAT4.7K |
| R3 | RC:NAT5.6K |
| R7 | RC:NAT47K |
| C1,C4 | CT:IVR33 |
| C2,C3,C6 to C9 | CC:FK16Y5V1H104 |
| C 5 | CK:SXE25VB10 |
| C10,C11,C12 | CC:0.01u |
| J1 | KO:440-8S15 |
| J2 | JT:174074-9 |
| J3 | JT:174074-6 |
| | |
| | |




Description of Operation

General

This board contains the microprocessor, the Liquid Crystal Display, the Operator Keyboard and the Power Supply circuitry.


The processor, U1, will normally be OFF and the scale will be using minimal power. When the ON/OFF key, S12, is pressed transistor Q5 will turn ON and provide a LO input to the processor at pin 46. Transistors Q4 and Q1 will turn ON and regulator U4 will provide power to the processor while the button is pressed. When the button is released the power will be held on by an output from the processor on pin 47. U4, in conjunction with C6, provides a reset signal to pin 15. Transistors Q2 and Q3 detect the voltage difference between Vin and Vout of U4. If this difference is less than 0.7v then Q3 provides a low battery signal to the processor on pin 45.

The E²PROM, U2, provides non-volatile memory for calibration data etc. The NAND gate, U3(a), allows the processor to count clock pulses, via the CKI input, during the second stage of the A to D conversion. The keypad input is read as a 3 x 4 matrix by the processor. The buzzer BZ is sounded by a 4096 Hz clock on pin 19. An output from the processor, on pin 29, is used to switch the



Push SW12 (Power ON)


Vin = 6.5 to 12 volts Vout = 5.0 +/- 0.25 volts Vres = Vo -0.25 +/- 0.05 volts Vlb = Vo+0.7+/- 0.01 volts



FS Series • Section E


Parts Locate






| REF. | Part Number | Description |
|------|-------------|--------------------------|
| 1 | MC27051.005 | Battery Box Screw |
| 2 | MM27048.021 | Battery Box Screw Spacer |
| 3 | MC27024.020 | BATTERY Box |
| 4 | MA10:ECLIP | E Clip - FS Battery Box |






| REF. | Part Number | Description |
|------|-------------|-----------------------------------|
| 1 | MC07624.005 | Corner Overload Stop -6 kg |
| 2 | MM07609.000 | Base Plate Complete With Nutserts |
| 3 | 05035100 | Load Cell FS-LC6k |
| 4 | FSM060001 | M6 x 30mm Skt Hd Cap Screw S/S |
| 5 | | M6 Washer - 14mm OD x 1.2mm S/S |
| 6 | MC07661.005 | Centre Overload Stop - Female |
| 7 | FWM050001 | M5 Washer - 11.5mm OD x 0.8mm S/S |
| 8 | FNM050001 | M5 Full Nut : S/S |
| 9 | MC07629.005 | Centre Overload Screw - Male |

FS-15kg Baseplate Assembly




| REF. | Part Number | Description |
|------|-------------|-----------------------------------|
| 1 | MC07625.005 | Corner Overload Stop - 15 kg |
| 2 | MM07609.000 | Base Plate Complete With Nutserts |
| 3 | 05035200 | Load Cell FS-LC15k |
| 4 | FSM060001 | M6 x 30mm Skt Hd Cap Screw S/S |
| 5 | FWM060002 | M6 Washer - 14mm OD x 1.2mm S/S |
| 6 | MC07662.005 | Centre Overload Stop - Female |
| 7 | FWM050001 | M5 Washer - 11.5mm OD x 0.8mm S/S |
| 8 | FNM050001 | M5 Full Nut : S/S |
| 9 | MC07629.005 | Centre Overload Screw - Male |

FS- 30kg Baseplate Assembly




| REF. | Part Number | Description |
|------|-------------|-----------------------------------|
| 1 | MC07626.005 | Corner Overload Stop - 30 kg |
| 2 | MM07609.000 | Base Plate Complete With Nutserts |
| 3 | 05035300 | Load Cell FS-LC30k |
| Д | FSM060001 | M6 x 30mm Skt Hd Cap Screw S/S |
| 5 | FWM060002 | M6 Washer - 14mm OD x 1.2mm S/S |
| 6 | MC07662.005 | Centre Overload Stop - Female |
| 7 | FWM050001 | M5 Washer - 11.5mm OD x 0.8mm S/S |
| 8 | FNM050001 | M5 Full Nut : S/S |
| 9 | MC07629.005 | Centre Overload Screw - Male |
| 10 | FWM050001 | M5 x 25 Bolt |
| 11 | | Reinforcement Bar |

Base Cover Assembly




| REF. | Part Number | Description |
|------|-------------|-----------------------------------|
| 1 | MM07635.000 | Level Vial Assembly |
| 2 | MM07618.005 | Column Support Bracket : Complete |
| 3 | MC07606.005 | Base Cover |
| _ 4 | FSM040002 | M4 x 6 mm Pan Head Screw |
| 5 | MA07:B48285 | Foot Screw (M8) |
| 6 | FSM060002 | M6 x 12 mm Skt Head Cap Screw |
| 7 | FWM060003 | M6 Washer - Spring S / S |

Load Pan Assembly




| REF. | Part Number | Description |
|------|--------------|--|
| 1 | MC07669.005 | Platform |
| 2 | MC07654.021 | Centre Pad |
| 3 | FSM060003 | M6 x 35 CSK Skt Head Screw : S / S |
| 4 | MC07642.014 | Platform Support Plate |
| 5 | FNM030001 | M3 Full Nut : S / S |
| 6 | MC07666.020 | Screw Guide |
| 7 | FSM030001 | M3 x 10 mm Pan Head X/Rec Mt Screw : S/S |
| 8 | MA10:NO.5601 | Cap Grommet (MG-1) |
| 9 | FSM040003 | M4 x 12mm Csk Head X/Rec Mt Screw : S/S |
| 10 | MC07651.021 | Corner Pad |
| 11 * | MC07661.005 | Centre Overload Stop - FS6K |
| 11 * | MC07662.005 | Centre Overload Stop - FS15K / FS30K |
| | | |
| | | * Select For Scale Capacity |

Load Pan Assembly - Casting




| REF. | Part Number | Description |
|------|--------------|--|
| 1 | MC07669.005 | Platform |
| 2 | MC07654.021 | Centre Pad |
| 3 | FSM060003 | M6 x 35 CSK Skt Head Screw : S / S |
| 4 | MC07642.014 | Platform Support Plate |
| 5 | FNM030001 | M3 Full Nut : S / S |
| 6 | MC07666.020 | Screw Guide |
| 7 | FSM030001 | M3 x 10 mm Pan Head X/Rec Mt Screw : S/S |
| 8 | MA10:NO.5601 | Cap Grommet (MG-1) |
| 9! | FSM040003 | M4 x 12mm Csk Head X/Rec Mt Screw : S/S |
| 10 | MC07651.021 | Corner Pad |
| 11!* | | Centre Overload Stop - FS6K |
| 11!* | MC07662.005 | Centre Overload Stop - FS15K / FS30K |
| | | |
| | | * Select For Scale Capacity. |

Base Plate Assembly - Casting




| REF. | Part Number | Description |
|------|-------------|--------------------------------------|
| 1 | MC07629.005 | Centre Overload Scew - Male |
| 2 | FNM050001 | M5 Full Nut - S/S |
| 3 * | 05035100 | Loadcell FS - LC6k |
| 3 * | 05035200 | Loadcell FS - LC15k |
| 3 * | 05035300 | Loadcell FS - LC30k |
| 4 | FSM060001 | M6 x 30mm Skt. Hd. Cap Screw S/S |
| 5 | FWM060002 | M6 Washer - 14mm OD x 1.2mm S/S |
| 6 * | MC07624.005 | Cornerload Stop - 6kg |
| 6 * | MC07625.005 | Cornerload Stop - 15kg |
| 6 * | MC07626.005 | Cornerload Stop - 30kg |
| | | |
| | | * Select according to scale capacity |

Cable Cover Assembly




| REF. | Part Number | Description |
|------|-------------|--|
| 1 | FSM030002 | M3 x 5 mm Pan Head X/Rec M/T Screw : S/S |
| 2 | MM07620.005 | Cable Cover With Nutsert |

Indicator Pod Assembly




| REF. | Part Number | Description |
|------|-------------|--|
| 1 | MC27080.020 | Display Window |
| 2 | FSI04AB0001 | 4AB x 1/4" Pan Head X/Rec S/T Screw :ZP |
| 3 | EA7PZ:2457 | Analog Board |
| 4 | MC27084.021 | O Ring |
| 5 | FSM030010 | M3 x 8 mm Mush Head X/Rec MT Screw : S/S |
| 6 | MC27062.005 | Sealing Screw - Long |
| 7 | MC27021.020 | Under Case |
| 8 | EA7PZ:2458 | Power Board - 'B' type only |
| 9 | MC27059.021 | Upper Case Seal |
| 10 | FSM030003 | M3 x 6 mm Pan Head X/Rec MT Screw : ZP |
| 11 | FWI01080001 | M3 Spring Washer |
| 12 | EA7PZ:2455A | Main Board for FS - A * |
| | EA7PZ:2455B | Main Board for FS - B * |
| 13 | MC27054.000 | Upper Case Unit |
| | | |
| | | * Select According To Model |

▼ Indicator Assembly



| REF. | Part Number | Description |
|------|--------------|--|
| 1 | MC27024.020 | Battery Box |
| 2 | MC27027.021 | Battery Box Seal |
| 3 | MA04:B47799 | Twin Coil Spring |
| 4 | MA04:B47801A | Coil Spring (-) |
| 5 | MA04:B47800A | Coil Spring (+) |
| 6 | MC27030.021 | Cable Boot |
| 7 | MC27033.005 | Boot Retaining Plate |
| 8 | MC27036.005 | Cal Switch Cover |
| 9 | MC50347.000 | Cal Switch Seal |
| 10 | MC11517.021 | Cable Grommet |
| 11 | MC27045.021 | Cap |
| 12 | MC27021.020 | Under Case |
| 13 | | Load Cell Cable |
| 14 | MC11519.005 | Grommet Retaining Plate |
| 15 | MC11510.005 | Indicator Bracket Axis |
| 16 | MC11513.005 | Indicator Bracket |
| * 17 | MA10:SK-34 | Screw Knob |
| 18 | MA10:NO.5602 | Cap Grommet (MG-2) |
| 19 | MM11504.000 | Column Cap Complete With Nutserts |
| 20 | MC11501.005 | Column - FS |
| 21 | FSM030005 | M3 x 8 mm Self Tapping Screw |
| 22 | MC27065.005 | Sealing Screw - Short |
| 23 | FSM040004 | M4 x 8 mm Csk Head X/Rec MT Screw :S/S |
| 24 | FSM040005 | M4 x 8 mm Pan Head X/Rec MT Screw :S/S |
| * 25 | FSM060004 | M6 x 16 mm Hex Head Set Screw :S/S |
| | | |
| | | * Later models these parts combined |



FS Series • Section F

Initialisation


Characteristic Settings



The FS scale may be set up to suit differing market requirements by use of the characteristic [functions.


To amend the settings use the procedure below.





Locate and remove the CAL switch cover






- Press the CAL switch.
- O The display will show


kg






- Press the C key.
- O The kg will disappear from the display.






- Press the 5, 0, 3 keys in turn.
- O The weight display will show 5 13.





- Press the POWER ON/OFF key.
- O The display will show [| []





- Use the numeric keys to set the required value see the table below, and press the POWER ON/OFF key.
- O The display will show [2]
- Continue in this way until all the ☐ funtions have been set.



The Characteristic Settings

| [] | Model Selection. |
|------------|------------------------------|
| [2 | Metric / Imperial Selection. |
| [3 | Must be set to 2 |
| [4 | Must be set to [] |
| <i>E</i> 5 | Must be set to [] |
| £ 5 | Country Code. |
| | |

| ~ | | | |
|---|-----|----------------------------|-------|
| ı | - 1 | O O O O O O O O O O | |
| 1 | 1 | | aciiv |
| _ | • | | |

This characteristic sets the scale capacity or allows selection of the Test Mode.

| <i>[</i>] | FS 6K | |
|------------|-----------|--|
| 1 | FS 15K | |
| 2 | FS 30K | |
| 3 | Test Mode | |

[2 Metric / Imperial

This characteristic sets the scale measurement unit.

| <i>[</i>] | Metric | | |
|------------|----------|--|--|
| 1 | Imperial | | |

[3 Factory Only Facilities

This characteristic must be set to 2.

| 0 | Factory Use Only |
|---|-----------------------------|
| 1 | Factory Use Only |
| 7 | This value must be selected |
| 3 | Factory Use Only |

| 14 | Factory | Only | Facilities |
|----------|---------|--------|------------|
| <u> </u> | Ideloty | Office | rucilles |

This characteristic must be set to [].

- This value must be selected


 Factory Use Only
- **E5** Factory Only Facilities

This characteristic must be set to [].

- This value must be selectedFactory Use Only
- **Country Selection**

This characteristic sets the scale to match the local market requirements.

| <i>[</i>] | Japan / U.S.A. |
|------------|----------------|
| 1 | Australia |
| 2 | Europe |



FS Series • Section G

Recommended Spare Parts

Distributor Items

| Qty. | Part Number | Description |
|------|---------------|--------------------------|
| 1 | 05035100 | Load Cell FS-LC6k |
| 1 | 05035200 | Load Cell FS-LC15k |
| 1 | 05035100 | Load Cell FS-LC30k |
| 3 | MC27024.020 | Battery Box |
| 5 | MC27027.021 | Battery Box Seal |
| 3 | MC27030.021 | Cable Boot |
| 1 | MC27035.005 | Boot Retaining Plate |
| 3 | MC27036.005 | Calibration Switch Cover |
| 5 | MC27045.021 | Cap |
| 5 | MC27051.005 | Battery Box Screw |
| 5 | MC27059.021 | Upper Case Seal |
| 5 | | Sealing Screw - Long |
| 5 | MC27065.005 | Sealing Screw - Short |
| 5 | MC27080.020 | |
| 10 | MC27084.021 | O'Ring BS006 |
| 5 | MM27048.021 | Battery Box Screw Spacer |
| 1 | EA7PZ:2455A | Main Board Unit - FSKA |
| 1 | EA7PZ:2455B | Main Board Unit - FSKB |
| 1 | EA7PZ:2457 | Analog Board Unit - FS |
| 1 | EA7PZ:2458 | Power Board Unit - FSKB |
| 12 | ECEB:C-1.5V | Battery - C Size |
| 3 | MA10:ECLIP | E Clip - FS Battery box |
| 5 | MC07651.021 | Corner Pad |
| 2 | MC07654.021 | Centre Pad |
| 5 | MC07666.005 | |
| 5 | MC11510.005 | Indicator Bracket Axis |
| 5 | ECFS:EAWK-500 | 500 mA Fuse |



Service Center Items

| Qty. | Part Number | Description |
|------|-------------|---|
| 2 | MC11513.005 | Indicator Bracket |
| 10 | MC11517.021 | Cable Grommet |
| 2 | MC11519.005 | Grommet Retaining Plate |
| 5 | MC11596.000 | Spanner Set |
| 2 | MC27021.020 | |
| 5 | MC27024.020 | Battery Box |
| 10 | MC27027.021 | Battery Box Seal |
| 10 | MC27030.021 | Cable Boot |
| 2 | MC27033.005 | Boot Retaining Plate |
| 5 | MC27036.005 | Cal Switch Cover |
| 10 | MC27045.021 | Cap |
| 20 | MC27051.005 | Battery Box Screw |
| 2 | MC27054.000 | Upper Case Unit |
| 5 | MC27059.021 | Upper Case Seal |
| 5 | MC27062.005 | |
| 5 | MC27065.005 | Sealing Screw - Short |
| 10 | MC27080.020 | |
| 25 | MC27084.021 | |
| 5 | MC50361.000 | Label Basework Capacity FS6K |
| 5 | MC50363.000 | Label Basework Capacity FS15K |
| 5 | | Label Basework Capacity FS30K |
| 5 | | Label Model Identification FS6KA |
| 5 | | Label Model Identification FS6KB |
| 5 | | Label Model Identification FS15KA |
| 5 | <u> </u> | Label Model Identification FS15KB |
| 5 | MC50391.000 | Label Model Identification FS30KA |
| 5 | | Label Model Identification FS30KB |
| 5 | | Label FCC Label |
| 5 | | * Label Sheet FS-6K (Metric Version) * |
| 5 | | * Label Sheet FS-6KEG (Imperial Version) * |
| 5 | MC50433.000 | |
| 5 | | * Label Sheet FS-15KEG (Imperial Version) * |
| 5 | | * Label Sheet FS-30K (Metric Version) * |
| 5 | | * Label Sheet FS-30KEG (Imperial Version) * |
| 2 | | Base Plate Complete With Nutserts |
| 2 | MM07618.005 | 1 |
| 2 | MM07620.000 | I |
| 2 | MM11504.000 | |
| 20 | MM27048.021 | |
| 3 | 05035100 | Load Cell FS-LC6K |
| 3 | 05035200 | Load Cell FS-LC15K |
| 3 | 05035300 | Load Cell FS-LC30K |
| 3 | EA7PZ:2455A | |
| 3 | EA7PZ:2455B | |
| 3 | EA7PZ:2457 | Analog Board Unit - FS |
| 3 | EA7PZ:2458 | Power Board Unit - FSKB |
| 60 | ECEB:C-1.5V | Battery C-Size |
| 20 | FNM050001 | M5 Full Nut :S/S - 8mm A/F |

| 20 | FSI04AB0001 | 4AB x 1/4" Pan Head X/Rec S/T Screw :ZP |
|-----|---------------|--|
| 20 | FSI04AB0002 | 4AB x 3/8" Pan Head X/Rec S/T Screw :S/S |
| 20 | FSM030001 | M3 x 10mm Pan Head X/Rec MT Screw :S/S |
| 20 | FSM030002 | M3 x 5mm Pan Head X/Rec MT Screw :S/S |
| 20 | FSM030003 | M3 x 6mm Pan Head X/Rec MT Screw :ZP |
| 20 | FSM030004 | M3 x 8mm Pan Head X/Rec MT Screw :S/S |
| 20 | FSM030006 | M3 x 6mm Csk Head X/Rec MT Screw :ZP |
| 20 | FSM040002 | M4 x 6mm Pan Head X/Rec MT Screw :S/S |
| 20 | FSM040003 | M4 x 12mm Csk Head X/Rec MT Screw :S/S |
| 20 | FSM040004 | M4 x 8mm Csk Head X/Rec MT Screw :S/S |
| 20 | FSM040005 | M4 x 8mm Pan Head X/Rec MT Screw :S/S |
| 20 | FSM060001 | M6 x 30mm Skt Head Cap Screw :S/S |
| 20 | FSM060002 | M6 x 12mm Skt Head Cap Screw :S/S |
| 20 | FSM060003 | M6 x 35mm Csk Skt Head Screw :S/S |
| 20 | FSM060004 | M6 x 16mm Hex Head Set Screw :S/S |
| 20 | FWI0180001 | Washer -1/8" x 1/32" x 1/32" Spring :S/S |
| 20 | FWI0180002 | Washer - 1/8" Nylon |
| 20 | FWI0180003 | Washer - 1/8" Flat :S/S |
| 20 | FWM050001 | M5 Washer - 11.5mm OD x 0.8mm :S/S |
| 20 | FWM060002 | M6 Washer - 14mm OD x 1.2mm :S/S |
| 20 | FWM060003 | M6 Washer - Spring :S/S |
| 5 | FXM080001 | M8 Nutsert |
| 10 | MA10:ECLIP | E Clip -FS Battery Box |
| 2 | MC07606.005 | Base Cover |
| 2 | MC07612.114 | Base Plate |
| 5 | MC07615.005 | Base Nutsert |
| 2 | MC07618.105 | Column Support Bracket |
| 2 | MC07621.005 | Cable Cover |
| 5 | MC07624.005 | Corner Overload Stop -FS6K |
| 5 | MC07625.005 | Corner Overload Stop -FS15K |
| 5 | MC07626.005 | Corner Overload Stop -FS30K |
| 5 | MC07629.005 | Center Overload Screw - Male |
| 5 | MM07635.000 | Level Vial Assembly |
| 2 | MC07642.014 | Platform Support Plate |
| 20 | MC07651.021 | Corner Pad |
| 5 | MC07654.021 | |
| 2 | MC07661.005 | Center Overload Stop -FS6K |
| 2 | MC07662.005 | Center Overload Stop -FS15K/FS30K |
| _ 5 | MC07666.020 | Screw Guide |
| 2 | MC07669.005 | Platform |
| 2 | MC11501.005 | |
| 5 | | Indicator Bracket Axis |
| 20 | ECFS:EAWK-500 | Fuse 500mA |
| | | * Select According to Country |
| | | |