

# Digital Scale

## MAINTENANCE MANUAL

FS-6Ki  
FS-15Ki  
FS-30Ki



1WTPD4001514

# Contents

<b>1. Introduction .....</b>	<b>3</b>
1.1 Outline of Products.....	3
1.2 Models .....	3
1.3 About this manual .....	3
<b>2. Block Diagrams .....</b>	<b>4</b>
<b>3. Gravity acceleration correction .....</b>	<b>5</b>
<b>4. Calibration .....</b>	<b>6</b>
4.1 Calibration using a weight .....	6
4.2 CAL prohibition procedure.....	7
<b>5. Internal setting (Check mode) .....</b>	<b>8</b>
5.1 Check mode flow chart .....	8
5.2 " d-dSP " internal setting data .....	9
5.3 " tEST " Display, board, key check.....	10
5.4 " init " Initialize.....	11
5.5 " Fnc " Factory (C) function setting.....	12
5.6 " SHort0 " The data crection of input short.....	13
5.7 " SEt " Setting data .....	14
5.8 " CAL " Factory calibration.....	15
5.9 " dAtA " Data display .....	17
<b>6. Software Parameter Settings.....</b>	<b>18</b>
<b>7. Troubleshooting .....</b>	<b>20</b>
<b>8 Disassembly and assembly.....</b>	<b>26</b>
8.1 Disassembly .....	26
8.2 Assembly.....	29
<b>9 Initialization &amp; Display Check.....</b>	<b>34</b>
9.1 Check mode .....	34

9.2	Initialize .....	34
9.3	Model setting .....	34
9.4	Temperature coefficient setting .....	34
9.5	Calibration.....	35
10.	Function setting list.....	36
11	User Function setting list .....	37
12	Option .....	41
12.1	OP-02 (Battery).....	41
12.1.1	Using the OP-02 SLA Battery .....	41
12.2	OP-03 (RS-232C/Relay output).....	43
12.2.1	Installation .....	43
12.2.2	OP-03 Specifications .....	44
12.3	OP-04 (RS-422/485/Relay output).....	46
12.3.1	Installation .....	46
12.3.2	OP-04 Specifications .....	47
13	Exploded View and Parts List.....	49
14	Circuit diagram .....	55
15	Parts layout and parts list.....	58
16	Wiring Diagram .....	65
17	Specifications.....	66



## 1. Introduction

The model name of this manual corresponds.



### 1.1 Outline of Products

The FS-i scales are based on the principal of detecting a weight using a load cell transducer. A load cell has strain gages bonded to its surface to detect a small change of strain. When a mass is placed on the weighing pan that is attached to the load cell, the force generated by a mass causes a small change of strain in the load cell. The change is transmitted to the strain gages and the resistance of strain gages changes its value. This small change of the resistance is converted to the voltage signal that is directly proportional to the force. The voltage is amplified and sent to an analog to digital converter to be digital value. The microprocessor calculates the weight value and shows it on the display.



### 1.2 Models

FS-i Series

FS-6Ki	Max = 6kg, d = 0.002kg / 0.001kg / 0.0005kg
FS-15Ki	Max = 15kg, d=0.005kg / 0.002kg / 0.001kg
FS-30Ki	Max = 30kg, d=0.01kg / 0.005kg / 0.002kg



### 1.3 About this manual

Every care has been taken during the manufacturing process of this scale to ensure that it will perform accurately and reliably for many years.


The intent of this manual is to make maintenance as easy as possible for you with a step-by-step guide through the in's and out's of the scale, or related products. Please let us know if it has accomplished the just stated goal - what works, what doesn't, and what we might have left out. We ask that you read through the entire owner's Instruction Manual, and this maintenance manual before starting any work.

When a customer has a problem, make sure that: the Best Conditions for Weighing, have been met, the scale has been calibrated and adjusted correctly, and the power is connected correctly. Next, look at the Fault Finding section, and the various flow charts.

*Keep your work area clean, remember how something came apart, and, always calibrate the scale after you have worked on it.*



## 2. Block Diagrams





### 3. Gravity acceleration correction

When the scale is first used or has been moved to different place, it should be calibrated using a calibration weight.

But if a calibration weight is not available, the gravity acceleration correction will compensate the scale. Change the gravity acceleration value of the scale to the value of area where the scale will be used. Refer to the gravity acceleration map appended to the end of this manual.

**NOTE:**

It is not necessary to set the gravity acceleration correction when calibrating the scale with a calibration weight at the place where it is to be used.

- Step 1. At Step 3. of the previous section “4.1 Calibration using a weight”, enter a new value using 10-key pad.

The integral part “9” is fixed and enter the value after the decimal point.

If you hit the wrong number, press the **C** key. The value returns to the original number. Enter again.

- Step 2. Press the **ENT** key, then the [ CAL 0 ] will be displayed.

- Step 3. If necessary to calibrate the scale using a calibration weight, go to step 5 of “4.1 Calibration using a weight”. To finish the setting, turn the power off.



## 4. Calibration

This function adjusts the scale for accurate weighing.  
Calibrate the scale in the following cases.

- When the scale is first used.
- When the scale has been moved.
- When the ambient environment has changed.
- For regular calibration.

Loose the lock screws on the rear side of the display pod, and remove the CAL switch cover. Then, there is a calibration switch inside.



### 4.1 Calibration using a weight

Step 1. Warm up the scale for at least half an hour with nothing on the weighing pan.

***Change Function setting “F1” or place something on the pan to disable the auto power-off function.***

Step 2. Press and hold the calibration (CAL) switch until **CAL** appears, and release the switch.

***Press and hold **0** key for about 5 seconds, then you can also enter the calibration mode.***

***Press the **ON/OFF** key or CAL switch to exit without calibration.***

Step 3. Press the **ENT** key, then the gravity acceleration value will be displayed.  
***It is not necessary to set the gravity acceleration value when calibration the scale with a calibration weight at the place where it is to be used (See the section about the gravity acceleration correction.)***

Step 4. Press the **ENT** key, then the **CAL 0** will be displayed.

Step 5. Make sure that there is nothing on the weighing pan, and wait until the STABLE annunciator turns on.

Step 6. Press the **ENT** key, The scale calibrate the zero point, and the display shows “ SPn 1 ” and the weight value to calibrate (SPAN calibration)  
***The weight value is equal to the capacity. When you enter with “kg” or “g” mode, then the value is “kg”. Entering with “lb” or “oz”, then “lb”.***  
If you do not need SPAN calibration, turn the power off to exit from the calibration procedure.

Step 7. To calibrate with the different weight, change the displayed value using the 10-key pad.

If you hit the wrong number, press the **C** key. The value returns to the capacity and enter again.

Step 8. Place the calibration weight on the pan with the same value as displayed, and wait until the STABLE annunciator turns on.

Press the **ENT** key. The scale calibrate SPAN and **End** will be displayed. Remove the weight from the pan, and turns the power off.



## 4.2 CAL prohibition procedure

Step 1. Press and holding **CAL** switch and **ZERO** key. Then press **ON/OFF** Key. Display it as "P-X. XX." (Program version shown)

Step 2. Press the **ENT** key and go into the check mode. " d-dSP " is displayed.

Step 3. Press the **UNITS** key 3 times. " Fnc " is displayed.

Step 4. Press the **ENT** key and go into the C function setting mode. " C01- " is displayed. The number is blinking.

Step 5. Press the **ENT** key to enter the C1 function setting mode. " C01-X " is displayed. " X " is blinking.

Step 6. Using a 10-key pad to change the displayed value " C01-1 ". Set Calibration prohibition mode. 1 of the right is blinking.

Step 7. Press the **ENT** key. " End " is displayed for a few second then " SHort 0 " is displayed.

Step 8. Press the **ON/OFF** key to turn the power off.

Remarks:

C1 = 0:CAL permission    **CAL** switch and **ZERO** key

C1 = 1:CAL permission    **CAL** switch, **ZERO** prohibition


C1 = 2:CAL permission    **CAL** only



## 5. Internal setting (Check mode)



### 5.1 Check mode flow chart




\* Press the [CAL] switch back to the weighing mode.



## 5.2 "d-dSP" internal setting data

[DISP]	key	Back light ON or OFF
[UNITS]	key	Change display item.
[ZERO]	key	Display ZERO Only 6, 7
[C]	key	Turn back light off, then exit. Go to the "tEST"

1. Weight A/D count



2. Weight A/D count (After the average)




3. Weight A/D count (After the correction for temperature)




4. Weight A/D count (After the correction for creep)




5. Temperature A/D count (After the average)



6. Internal count



7. Display count



[UNITS] key



### 5.3 "tEST" Display, board, key check

- Step 1. Number sift
- Step 2. Number Inclement
- Step 3. The segment lights up in turn.
- Step 4. The analog bar shift
- Step 5. The segment lights up in turn.
- Step 6. All display turn on.

Output HI signal from 4 pin to 10 pin of J2. It changes to the LO signal in turn every about 0.3 seconds.

J2 - 4 pin : RS422/485 judgment port

5 pin : Comparator HI

6 pin : Comparator OK

7 pin : Comparator LO

8 pin : TXD terminal

9 pin : RXD terminal

10 pin : RS422/485 input/output switching CNT

- Step 7. Press the [SAMPLE] key to perform key check.

[SAMPLE]	key : " 1"	displayed	
[KEY]	key : " 2"	displayed	
[RECALL]	key : " 3"	displayed	
[ON/OFF]	key : " 4"	displayed	
[HI]	key : " 5"	displayed	
[LO]	key : " 6"	displayed	
[STORE]	key : " 7"	displayed	
[PT]	key : " 8"	displayed	
[DISP]	key : " 9"	displayed	
[2]	key : "10"	displayed	
[UNITS]	key : "11"	displayed	
[TARE]	key : "12"	displayed	
[ENT]	key : "13"	displayed	"HI" turned on
[C]	key : "14"	displayed	"OK" turned on
[0]	key : "15"	displayed	"LO" turned on
[ZERO]	key : "16"	displayed	Backlight on, Buzzer on
[CAL]	key : "17"	displayed	
[CAL]	key		end and display change to " init "


\*Press and hold



## 5.4 " init " Initialize

It does all the initialization of EEPROM.

Input short data, the correction-for-temperature data, the CAL data, the factory function, the user function, the user setting data (The bound pair value, the target value and so on)




Initiarize each value, then go to "Fnc"



## 5.5 "Fnc" Factory (C) function setting

- [0]-[9] key : The entry of the number of the functions.  
[C] key : It returns to the "C01" display.  
[ENT] key : It fixes the number of the functions in case of being the corresponding number of the C functions and it move to the setting of the number of the function selection. The buzzer is sounding just as it is when not corresponding.


Step 1. The setting of the number of the functions.



- [0]-[9] key : The entry of the number of the function choices  
[C] key : It returns to the subscription value in the last time.  
[ZERO] key : It goes to the following number of the functions in case of being the corresponding number of the function choices.  
The buzzer is sounding just as it is when not corresponding.  
[ENT] key : It subscribes EEP by the "End" display in case of being the corresponding number of the function choices and it goes to the "SHort0" display.  
The buzzer is sounding just as it is when not corresponding.

Step 2. The setting of the number of the function choices


- It first displays the value which is subscribed at present.
- When the value which is the same as the value which is subscribed at present is displaying, the stable mark lights up.



## 5.6 "SHort0" The data creation of input short


It puts the following jig (the input short jig) in J4 and it captures a value after making a load-cell 0mV/V after making thermosensitivity resistance  $0\ \Omega$ .

If capturing a value, it pulls out and it joins a jig to the original cell cable once more.





## 5.7 "SEt" Setting data





## 5.8 "CAL" Factory calibration

### Step 1. Temperature setting

vvvvv  
2 0  
^^^^^

[0]-[9] 10key pad input  
[C] It returns to the subscription value in the last time.



[ENT] key  
The within-the-limits  
To (0-40)'s fixing a temperature value and setting Step 2.  
In the range  
The buzzer is sounding just as it is as the error.

### Step 2. Gravity acceleration correction

vvvvvv  
9 . 7 9 8 5  
^^^^^^^

[0]-[9] 10key pad input  
[C] It returns to the subscription value in the last time.



[ENT] key  
The within-the-limits  
If gravity acceleration correction value within 9.7700 to  
9.8350, store the value. Then go to Step 3.  
In the range  
The buzzer is sounding just as it is as the error.

### Step 3. CAL 0

○ C A L 0


[ENT] key : Stable (Store the CAL 0 data, Then go to  
Step 4.)  
Unstable (It doesn't recognize as the key)



S P n 1

Displayed for 1.5 seconds

#### Step 4. CAL S



#### Step 5. End






## 5.9 "dAtA" Data display

[UNITS] key : The display item change.

[C] key : It is possible to pull out a mode and it goes to the "d-dSP" display.





## 6. Software Parameter Settings

### C1 Calibration

- 0 Both are a permission
- 1 Both are a ban
- 2 Only [CAL] is a permission

### C2 The maximum weight

- 0 6kg
- 1 15kg
- 2 30kg

### C3 Unit

- 0 The metric (kg,g)
- 1 The non metric (kg,g,lb,oz,lb-oz)

### C4 The zero-powering possible range

- 0 ±10%
- 1 ±50%

### C5 Sri Lanka specification

- 0 The invalidity
- 1 The validity

### C6 The decimal point

- 0 . (The point)
- 1 , (The comma)

### C7 The tare clearance by zero key at the time of NET

- 0 None
- 1 Yes

### C8 NET content weight display

- 0 The display count
- 1 The internal count

### C9 Preset tare

- 0 The ban
- 1 The permission

C10 (lb – oz) Display

- 0 The ban
- 1 The permission

C11 The possible range of zero push

- 0  $\pm 2\%$
- 1 Unlimited

C12 The range fixation

- 0 It is due to the setting of F2
- 1 It fixes on  $F2=0(1/3000)$
- 2 It fixes on  $F2=1(1/6000)$
- 3 It fixes on  $F2=2(1/12000)$



## 7. Troubleshooting

This section can be photocopied and used as a check sheet.  
Simply tick the boxes provided after each step is successfully completed.

### Troubleshooting

- # Check the Keyboard to see if it is functioning properly. (See Keyboard Check)
- # Zero calibration may be needed if the **ZERO** key will not set the display to zero, or if "----" is displayed when the power is turned on. (See Calibration section) .
- # If the display remains "E" or is not stable - then do a full recalibration, including resetting "g" if necessary. (see Calibration section)
- # If calibration is not possible:
  - If "-CAL E" is displayed when you press **ENT** key, the scale cannot enter the maximum capacity value because the calibration mass is under-weight (minus Calibration Error). Check everything is correctly set.
  - Check the analog and main boards for broken leads, and the cable from the Load Cell to J4 of the main board.
  - \* Don't forget to do a full recalibration, including resetting "g" (see Calibration section) if you make any electronic repairs.

### Load cell stopper check

- # If the weighing pan is loaded to just over full scale, does it hit the  ok overload stopper?

### Pan check

- # Is the weighing pan touching anything?  ok
- # Is the weighing pan mounted correctly?  ok
- # Is the weighing pan perfectly horizontal?  ok

### Power supply check

- # AC cable, the power board, the AC adapter (which is included in the indicator part) and Main board lead neatly or do the battery and main board lead neatly ?  ok
- # If pushing [ON/OFF] key, pulling out AC cable when a battery is included, is it turned on?  ok
- # Check the output of the Battery /AC cable to see that it is at least 5.8 volts.  ok

- # When pressing the **ON/OFF** key, check the resistance between S4 pins to see if they read less than  $10\ \Omega$ . If so, then it is normal.  ok
  - If not, replace the switch.  ok
  - If the resistance is correct but the problem remains, try a different main board.  ok
- # When the **ON/OFF** key is pressed, the voltage at J4 pins 3 and 6 should be  $5V \pm 10\%$ , and pin 18 of CPU (RESET) at  $\approx 5V$  (Hi).  ok

## CPU check

- # Check all solder connections.  ok
- # Check that the voltage between pin 3 and 6 of J4 of the main board, it should be  $5V \pm 10\%$ .  ok
- # Is the RESET at the Hi level? [ pin 18 of U1 (RESET) at  $\approx 5V$  (Hi)]  ok
- # Check the voltage levels for the LCD at U1 pin 1  $\approx 5.0V$ , 2  $\approx 3.3V$ , 3  $\approx 1.7V$   ok
- # Check that the clock pulse is 20MHz (see #1 Waveform table).  ok

## LCD check

- # Check the glass for cracks (visible as dark spots).  ok
- # Check the soldering for breaks.  ok
- # Check for missing segments during the sequential and 'power on' tests.  ok

## Backlight check

- # Whether or not to light up both two by the backlight?  ok
- # Is it a rank with the same light of the 2 corner backlight?  ok
- # Is the voltage LCD1-A, LCD2-A and GND about  $4V (\approx 4V)$ ?  ok

## LED check

- # Does the 3 color LED (the yellow, the green, the red) light up?  ok
- # Is it a rank with the same light of the 3 color LED (the yellow, the green, the red)?  ok
- # Is the directivity of the light the direction of the front?  ok
- # Is the voltage D3, D6, D9 of anode side and GND about  $4.5V (\approx 4.5V)$ ?  ok

## Buzzer check

- # Is the volume of the key click sound, the buzzer sound at the time of the comparator right?  ok
- # Is the timbre of the key click sound, the buzzer sound at the time of the comparator right?  ok
- # Is the frequency of the square wave of U1 from 26 pins 4.88 kHz?  ok

## Load cell check

- # Check the following cable assembly - pin to wire - connections of J4 on the main board:

1	Orange	<input type="checkbox"/> ok
2	Purple	<input type="checkbox"/> ok
3	Red	<input type="checkbox"/> ok
4	Green	<input type="checkbox"/> ok
5	Blue	<input type="checkbox"/> ok
6	White	<input type="checkbox"/> ok
7	Yellow	<input type="checkbox"/> ok

- # Check that the voltage between pins 1 & 6 of J4 is  $\approx$  2.5V.  ok
- # Check that the voltage between pins 2 & 6 of J4 is  $\approx$  2.5V.  ok
- # Check that the voltage between pins 3 & 6 of J4 is 5V  $\pm$ 10%.  ok
- # Check that the voltage between pins 4 & 6 of J4 is  $\approx$  2.5V.  ok
- # Check that the voltage between pins 5 & 6 of J4 is  $\approx$  2.5V.  ok
- # Check that the voltage between pins 4 & 5 of J4 is 0.5 ~ 2mV with no weight on the weighing pan.  ok
- # Check that the voltage between pins 4 & 5 of J4 is 5 ~ 8mV with full span weight on the weighing pan.  ok
- # Check that the voltage of U2 at pin 14 on the analog board is 5V  $\pm$ 10%.  ok
- # Check that the A/D converter waveforms are correct.  ok
- # Check that the wiring is correct.  ok
- # Check that the voltage is correct.  ok

## Other voltage check

RE-install the battery(OP-02), and the AC cable, if used.

- # Check that the voltage between pins J+ & J- is 7.5V(AC adaptor).  ok
- # Check that the voltage between pins BAT+ & BAT- is 6V(Battery).  ok
- # Check that the voltage between pins 2 & 4 of U14 is 5V.  ok
- # Check that the voltage between pins 2 & 4 of U15 is 5V.  ok
- # Check that the voltage between pins 1 & 2 of J2 is 5V.  ok

## Keyboard check

### Operation of each key

KEY:	Function:	
# [ON/OFF]	On and OFF of the power	<input type="checkbox"/> ok
# [RECALL]	It enters a memory call mode.	<input type="checkbox"/> ok
# [KEY]	It enters the key program mode of the target value.	<input type="checkbox"/> ok
# [SAMPLE]	It enters the sample create-mode of the target value.	<input type="checkbox"/> ok
# [PT]	It enters a preset tare setting mode.	<input type="checkbox"/> ok
# [STORE]	It enters a memory store mode.	<input type="checkbox"/> ok
# [LO]	It enters the key setting mode of the lower limit.	<input type="checkbox"/> ok
# [HI]	It enters the key setting mode of the upper value.	<input type="checkbox"/> ok
# [TARE]	It subtracts the weight of the tare.	<input type="checkbox"/> ok
# [UNITS]	It changes an unit of display.	<input type="checkbox"/> ok
# [2]	The entry which is ("2") in numeric key entry	<input type="checkbox"/> ok
# [DISP]	It changes an analog bargraph display.	<input type="checkbox"/> ok
# [ZERO]	It changes a display in zero.	<input type="checkbox"/> ok
# [0]	The entry which is "0" in numeric key entry.	<input type="checkbox"/> ok
# [C]	It clears an input value in numeric key entry.	<input type="checkbox"/> ok
# [ENT]	It subscribes a value in numeric key entry.	<input type="checkbox"/> ok
# [OP-03/04]	The data transmission by the OP-03/04 connection	
# [CAL]	It enters a calibration mode with Holding and pressing (about 2 seconds).	<input type="checkbox"/> ok

Remove the battery(OP-02), and the AC cable, if connected.

Check that each individual key is working by measuring the resistance between the pins of the switches.

The resistance with the key pressed should be less than 10Ω for:

# [SAMPLE]	between pins of S1	<input type="checkbox"/> ok
# [KEY]	between pins of S2	<input type="checkbox"/> ok
# [RECALL]	between pins of S3	<input type="checkbox"/> ok
# [ON/OFF]	between pins of S4	<input type="checkbox"/> ok
# [HI]	between pins of S5	<input type="checkbox"/> ok
# [LO]	between pins of S6	<input type="checkbox"/> ok
# [STORE]	between pins of S7	<input type="checkbox"/> ok
# [PT]	between pins of S8	<input type="checkbox"/> ok
# [DISP]	between pins of S9	<input type="checkbox"/> ok
# [2]	between pins of S10	<input type="checkbox"/> ok
# [UNITS]	between pins of S11	<input type="checkbox"/> ok
# [TARE]	between pins of S12	<input type="checkbox"/> ok
# [ENT]	between pins of S13	<input type="checkbox"/> ok
# [C]	between pins of S14	<input type="checkbox"/> ok
# [0]	between pins of S15	<input type="checkbox"/> ok
# [ZERO]	between pins of S16	<input type="checkbox"/> ok


# [CAL] between pins of S17  ok

If any of the above are out of the correct resistance range, that switch is defective

## Tolerance check

	Model	Linearity	Corner error(Test load)	
#	FS- 6Ki	$\pm 2g$	$\pm 2g( 2kg)$	<input type="checkbox"/> ok
#	FS-15Ki	$\pm 5g$	$\pm 5g( 5kg)$	<input type="checkbox"/> ok
#	FS-30Ki	$\pm 10g$	$\pm 10g(10kg)$	<input type="checkbox"/> ok

# Troubleshooting flow chart





## 8 Disassembly and assembly



### 8.1 Disassembly

Step 1. Remove weighing pan.




Step 2. Remove the cover.




Step 3. Remove two hexagon bolts that fix upper frame. Then remove the upper frame.





Step 4. Remove the upper frame.





- Step 5. Remove the ten screws that secure the rear panel of display. Then remove the rear panel.




- Step 6. Remove the Loadcell cable from the main board, then remove the cable clamp and core.




- Step 7. Extract the cable assembly of load cell from poll. Be careful not to damage to the cable assembly at this time.




Step 8. Remove the load cell cable from the base unit




Step 9. Remove the cover.



Step 10. Then remove the two screws.




Step 11. Remove the load cell unit. Load cell spacer is glued to load cell with silicon (Only small size). This spacer will use when the load cell is installed.






## 8.2 Assembly


- Step 1. Install load cell on base and fix from the reverse side of a basis with four hexagon bolts. Place the loadcell straight.
- It applies silicon between the load cell and spacer. (TORAY SE9140 or such a thing)
  - It puts the number which is the same as the time to have removed the number which puts a spacer. (Weighing pan side 3 pieces, base side 2 pieces. ( Only S size )



OK



NG





NG

- Step 2. Attach the cable clamp.




- Step 3. Attach the load cell.


Tighten torque:200kgf · cm



Step 4. Let the load cell cable assembly pass on the pole.




Step 5. Attach the cap and packing to load cell cable.




Step 6. It enlarges a little hole on the side of the main unit.




Step 7. Trough the load cell cable to hole of the main unit. Insert the packing too. Secure the cap.




Step 8. Take the load cell cable into the main unit.




Step 9. Round load cell cable to core 3 times.



Step 10. Connect the load cell cable onto the main board unit.



Step 11. Attach the upper frame.



Step 12. Secure the bolts of fixing upper frame.  
(Tighten torque: 200kgf · cm)



Step 13. Attach the cover.



Step 14. Attach the weighing pan.





## 9 Initialization & Display Check

Initialization readjustment is required when the load cell or main board is replaced.

Please do not initialize during regular repairs without first replacing the above-mentioned parts.

Since an important internal parameter will be lost if it is initialized, accuracy cannot be guaranteed unless it is readjusted.

The warm-up can shine sufficiently for the load-cell to match the temperature in the stable environment where there is little temperature change.



### 9.1 Check mode

- Step 1. Press and holding [CAL] switch and [ZERO] key, Then press [ON/OFF] to display "P-X.XX" (program version)
- Step 2. Press the [ENT] key to enter check mode. " d-dSP " is displayed.



### 9.2 Initialize

- Step 1. Press the [UNIT] key two times. " init " will be displayed.
- Step 2. Press the [ENT] key. " StorEd " will be displayed for about.



### 9.3 Model setting

- Step 1. The factory (C) It sets (referring to the function setting table clause) a function.
- Step 2. It becomes "SHort0" display when ending.



### 9.4 Temperature coefficient setting

- Step 1. [UNITS] It becomes "SEt" display when pushing a key.
- Step 2. Refer to step 6 of Internal setting. It subscribes the zero temperature coefficient, the span temperature coefficient of the new load-cell and being specified at the load-cell cable of the value. (The zero temperature coefficient=the span temperature coefficient)
- Step 3. It becomes "CAL" display when ending.



## 9.5 Calibration

- Step 1. Press the [ENT] key to enter temperature setting mode. "20" will be displayed and blinking.
- Step 2. Enter the temperature (the temperature around) of the load-cell with the numeric key and press the [ENT] key.
- Step 3. Go to the gravity acceleration correction. Then "9.7985" on the display blinks.
- Step 4. Enter the gravity acceleration with 10 key pad. Then press the [ENT] key.
- Step 5. Go to the CAL0 setting mode. Then " CAL 0" will be displayed.
- Step 6. It confirms that nothing is on the weighing pan and press the [ENT] key if the stable mark lights up.
- Step 7. "SPn 1" will be displayed 1.5 seconds. Then the display change to calibration weight value.
- Step 8. It puts a calibration weight which is the same as the display at the center of the weighing pan and press the [ENT] key if the stable mark lights up.

FS- 6Ki	6kg
FS- 15Ki	15kg
FS- 30Ki	30kg

- Step 9. "End" will be displayed about 1.5 seconds. Then "dAtA" will be displayed.



## 10. Function setting list

Function	FS-6Ki	FS-15Ki	FS-30Ki
C2	0	1	2

Function	----	-- JA	Approval	NTEP
C1	0	0	2	2
C3	1	0	0	1
C4	1	1	0	0
C5	0	0	0	0
C6	0	0	0	0
C7	0	1	1	0
C8	1	1	1	0
C9	1	1	1	1
C10	1	1	0	0
C11	0	0	0	0
C12	0	0	1	1

Function	----	-- JA	Approval	NTEP
F1	0	0	0	0
F2	0	1	0	0
F3	2	0	0	2
F4	0	0	0	0
F5	0	0	0	0
F6	2	2	2	2
F7	1	1	1	1
F8	1	1	0	0
F9	0	0	0	0
F10	1	1	3	3
F11	1	1	1	1
F12	1	1	1	1
F13	1	1	1	1
F14	0	0	0	0
F15	6	6	6	6
F16	0	0	0	0
F17	1	1	1	1
F18	00	00	00	00
F19	0	0	0	0
F20	1	1	1	1



## 11 User Function setting list

F1 Auto power off

- 0 OFF
- 1 ON

F2 Resolution

- 0 1/3000
- 1 1/6000
- 2 1/12000

\*2

F3 Unit

- 0 Kg
- 1 G
- 2 Lb
- 3 Oz
- 4 Lb-Oz

F4 Borate

- 0 2400 bps
- 1 4800bps
- 2 9600bps

F5 Bit, parity

- 0 7bit Even
- 1 7bit ODD
- 2 8bit NON

F6 Output mode

- 0 Stream
- 1 Command
- 2 [PRINT] key
- 3 Auto print +
- 4 Auto print +/-
- 5 Waiting (For RS422/485)

F7 The comparative size judgment value

- 0 Upper , Lower
- 1 Target value + upper, Target, Target value - Lower
- 2 Target value x upper [%] , Target, Target value x Lower [%]

F8 Comparator judgment condition

- 0 Not compare
- 1 Always compare
- 2 Compare at the time of stable
- 3 Always compare except around zero
- 4 Compare at the time of stable except around zero
- 5 Always compare more than around zero
- 6 Compare at the time of stable more than around zero

F9 Buzzer output

- 0 No sound
- 1 LO
- 2 OK
- 3 LO, OK
- 4 HI
- 5 LO, HI
- 6 OK, HI
- 7 LO, OK, HI

F10 Characteristic response

- 0 Quick measurement, Quick response
- 1 ↑ ↓
- 2 ↑ ↓
- 3 ↑ ↓
- 4 Slow measurement, Slow response

F11 Stable detection

- 0 Strictly judgment       $\pm 0.5$  count
- 1 ↑ ↓       $\pm 1.0$  count
- 2 Gentle judgment       $\pm 2.0$  count

F12 Stable detection time

- 0 Quickly      0.1 second
- 1 ↑ ↓      0.2 second
- 2 Slowly      0.5 second

F13 Zero tracking

- 0 No
- 1 Yes

F14 Key operate prohibition

- 0 NO
- 1 5 keys [ON/OFF], [ $\pm$ /ZERO], [TARE], [9/SAMPLE], [PRINT/ENT]
- 2 3 keys [ON/OFF], [ $\pm$ /ZERO], [TARE]

F15 LED Brightness

- 0 Dark
- 1 ↑
- 2 |
- 3 |
- 4 |
- 5 |
- 6 |
- 7 ↓
- 8 Bright

F16 Bar display select

- 0 Normal
- 1 Weighing mode
- 2 Weight check mode
- 3 No display

F17 Back light control

- 0 Always OFF
- 1 Always ON
- 2 Light on when the display change more than  $\pm 4$  count or key operation.  
Light off 30 seconds after stabilized.
- 3 Light on when the display change more than  $\pm 4$  count or key operation.  
Light off 60 seconds after stabilized.

F18 The equipment-identification-number

- 0 00 RS232C
- ~ 01 ~ 99 RS422/485
- 99

F19 RS control

- 0 NO RS232C
- 1 YES RS422
- 2 YES RS485

F20 Output format

- 0 Response
- 1 No response
- 2 UFC
- 3 MT



## 12 Option



### 12.1 OP-02 (Battery)


#### 12.1.1 Using the OP-02 SLA Battery

- The scale can be operated with an SLA (Sealed Lead Acid) battery that will be commercially available.
- The scale (with no other options) can be operated with a fully charged battery for;
  - LCD backlight OFF and Comparator light OFF: approximately 80 hours
  - LCD backlight OFF and Comparator light ON: approximately 55 hours
  - LCD backlight ON and Comparator light ON: approximately 25 hours
- The battery will take about 15 hours to be fully charged.
- The battery life will vary depending on how the scale is used, the ambient temperature and so on.



- Use a Yuasa Battery NP4-6 (6V, 4Ah).
- There will be risk of explosion if the battery is connected improperly or replaced with the incorrect type.
- Dispose of a used battery according to the local laws and regulations.

##### Installing the battery



1. Disconnect the main power cord from the outlet.
2. Remove the ten hexagon head screws and open the rear cover.  
***⚠ Take care not to drop the rear cover or the wires connecting between front display and rear cover will be damaged.***
3. Loosen the screws fixing the battery support and remove it.
4. Connect the wires inside the display pod to the battery.  
***⚠ Be sure to connect RED wire to positive (+ / RED) terminal and BLACK wire to negative (- / BLACK) terminal. Or there is a risk of explosion.***
5. Place the battery into the rear cover and fix with screws and battery support that removed at step 3 above.
6. Attach the rear cover to the front display firmly using the ten hexagon head bolts.
7. Connect the main power cord to the outlet.
8. Press the **ON/OFF** key and check that the scale works normally.
9. Disconnect the main power cord again and check that the scale still works.

### Charging the battery

- When the weight display shows "Lb !", the battery voltage is low in voltage and should be recharged. Connect the main power cord to the outlet. The charging process will start while the scale is powered on or not.
- When the battery is getting close to the low battery, the annunciator (PRECAUTION AGAINST LOW BATTERY) will come on. Prepare to charge the battery.
- The scale can be used while the battery is charging. After fully charged, the scale will change the charging process to trickle charge automatically.
- The battery cannot be charged with the OP-04 in operation. Turn the power off to charge.  
***☐ Charge the battery at a temperature between 0°C (32°F) and 40°C (104°F). Preferably 5°C (41°F) ~ 35°C (95°F) is recommended.***
- ☐ Charge the battery when using for the first time.***
- ☐ The battery must be recharged regularly if the scale is not used for a long period of time. Every 3 months in a warmer area and every 6 months in a cooler area will be needed.***




## 12.2 OP-03 (RS-232C/Relay output)

This interface allows the FS-i series to be connected with a multifunction printer or a personal computer, and the relay outputs for comparator result are obtained.

- The OP-03 unit includes an interface board, a connector cable, a cable gland and two screws (M3x6).

### 12.2.1 Installation




1. Disconnect the main power cord from the outlet.
  2. Remove the ten hexagon screws and open the rear cover.
  3. Connect the cable from external device through the cable gland to the terminal blocks on the interface board. Also connect a yellow/green wire inside the display pod directly to "FG" on the terminal block.
- ⚠ Take care not to drop the rear cover or the wires connecting between front display and rear cover will be damaged.***
4. Connect the connector cable included in the OP-03 to the connectors on the interface board and the main board inside the display pod.
  5. Fix the interface board with 2 M3 x 6 screws included in the OP-03.
  6. Tighten the cable gland and attach the rear cover to the front display firmly using the ten hexagon bolts.
  7. Connect the main power cord to the outlet.
  8. Set the function parameters F04, F05, F06, F18, F19 and F20 according your application.
- The OP-03 RS-232C must have settings F18-00 and F19-0.*

## 12.2.2 OP-03 Specifications

### RS-232C Specification

Transmission form	Asynchronous, bi-directional, half-duplex
Data format	Baud rate: 2400, 4800, 9600 bps
	Data: 7 bits + parity 1bit (even / odd) or 8 bits (non-parity)
	Start bit: 1 bit
	Stop bit: 1 bit
	Code: ASCII
	Terminator: C <sub>R</sub> L <sub>F</sub>




### Maximum rating of the Relay Output

The maximum rating of the relay output is as follows.


- Maximum voltage: 50V DC
- Maximum current: 100 mA DC
- Maximum ON resistance: 8 Ω

## Circuit diagram



- 1 Receive data RXD
- 2 Transmit data TXD
- 3 Data set ready DSR
- 4 Signal ground SG
- 5 Shield SHLD
- 6 Frame ground FG

FS-*i* is designed as DCE (Data Communication Equipment).



- 1 Relay output HI
- 2 Relay output LO
- 3 Relay output OK
- 4 Relay common COM




## 12.3 OP-04 (RS-422/485/Relay output)

This interface allows a personal computer to connect and control up to 16 FS-I scales and the relay outputs for comparator result are obtained.

- The OP-04 unit includes an interface board, a connector cable, two cable glands and two screws (M3x6).
- The relay output specifications are same as the OP-03. See “ 12.2.2 OP-03 Specifications”

### 12.3.1 Installation




- Installation is similar to the OP-03. See “12.2.1 Installation”
- Set the function parameters F04, F05, F06, F18, F19 and F20 according your application.
- The function setting F19-1 must be set for RS-422 and F19-2 must be RS-485. To connect more than one scale with comparator, set a different address to each scale by F18-##


### 12.3.2 OP-04 Specifications

#### RS-422/485 Specifications

Transmission form	Asynchronous, bi-directional, half-duplex
Data format	
Baud rate:	2400, 4800, 9600 bps
Data:	7 bits + parity 1bit (even / odd) or 8 bits (non-parity)
Start bit:	1 bit
Stop bit:	1 bit
Code:	ASCII
Terminator:	C <sub>R</sub> L <sub>F</sub>




Circuit diagram




## Example of connection

RS-422



RS-485




Connect TRM with RDB at the farthest FS-*i* from the host computer.


- The polarity (A, B) of the host computer signal depends on model. Check the technical manual of the computer.




## 13 Exploded View and Parts List



No.	Stock No.	Description	Quantity
1	1043009061	BASE(S)	1
2	1043009060	PAN SUPPORT(S)	1
3	1044018790	SPACER(S)	5
4	1054018787-2	COLLAR 8	4
5	1054018788	STOPPER BOLT	4
6	1074018789	STOPPER COVER	4
7	1043003955	PAN(S)	1
8	1073008853	CELL COVER	2
9	1074018398	LEVEL FOOT CASE	4
10	1074018399A	LEVEL FOOT BASE	4
11	1073008855	LEVEL FOOT 76	4
12	1073008851A	CORNER PAD FS	4
13	1064018396	CARBON CAP	1
14	1074018397	LEVEL VIAL HOLDER	1
15	110MR14	LEVEL VIAL MR14	1
16	110NK-3N	CABLE CRAMP	1
17	1043009062	POLE ASSY	1
18	1073008856	FOOT HOLDER	1
19	1074018400	LEVEL FOOT 45	1
20	1073008854	POLE BRACKET COVER	1
21	110DASB-625-8	CABLE BUSH	1
22	110DASB-1000-14	CABLE BUSH	1
23		LOAD CELL	1



No.	Stock No.	Description	Quantity
1	1043009059	BASE(M)	1
2	1043009058A	PAN SUPPORT(M)	1
3	1073008852B	CENTER PAD FS	1
4	1054018787-1	COLLAR 16	4
5	1054018788	STOPPER BOLT	4
6	1074018789	STOPPER COVER	4
7	1043007268	PAN-SUS304	1
8	1073008853	CELL COVER	1
9	1074018398	LEVEL FOOT CASE	4
10	1074018399A	LEVEL FOOT BASE	4
11	1073008855	LEVEL FOOT 76	4
12	1073008851A	CORNER PAD FS	4
13	1064018396	CARBON CAP	1
14	1074018397	LEVEL VIAL HOLDER	1
15	110MR14	LEVEL VIAL MR14	1
16	110NK-3N	CABLE CRAMP	1
17	1043009062	POLE ASSY	1
18	1073008856	FOOT HOLDER	1
19	1074018400	LEVEL FOOT 45	1
20	1073008854	POLE BRACKET COVER	1
21	110DASB-625-8	CABLE BUSH	1
22	110DASB-1000-14	CABLE BUSH	1
23		LOAD CELL	1




No.	Stock No.	Description	Quantity
1	1042001151	FRONT CASE	1
2	1074018362	BOLT CAP	2
3	1072001153A	PCB CHASSIS	1
4	1072001154A	INLET HOLDER	1
5	1042001152	REAR CASE	1
6	1054018373	EARTH BOLT	1
7	1073008825-1	LED LENS A	1
8	1073008825-2	LED LENS B	1
9	1073008825-3	LED LENS C	1
10	1084018374A	LENS TAPE	3
11	1044018360	CAL COVER	1
12	1064018365	CAL COVER PACKING	1
13	1074018361	BATTERY HOLDER	2
14	1054018371	12mm SPACER M3	3
15	1063008826	MAIN PACKING	1
16	1054008782	WP BOLT	9
17	1064008666	O-RING ( $\phi$ 5.5)	10
18	110P3	O-RING ( $\phi$ 6x2.8x1.9)	16
19	1044018366	O-RING HOLDER M4	6
20	1064018370	ST-16 INNER PACKING	1
21	1074018364	CABLE HOOK	2
22	1054008627	SEALING BOLT	1
23	1064018375	BATTERY SPONJI	1
24		KEY SHEET	1
25		MODEL LABEL	1
26	110DACL 11	CABLE GLAND DACL 11	1
27	110DACL 16	CABLE GLAND DACL 16	1
28	1084014720	BLANK SEAL B	4
29	1074016820	KEY TOP	16
30	54008881	CAL SCREW	2
31	110M6KNOB	SUPER KNOB	2
32	1044005255	SHIELD CASE A	1
33	1043004953	SHIELD CASE B	1
34	1083008926	MAIN PACKING TAPE	1
35	1084012455A	CAL KEY SHEET	1
36		MAIN PCB	1
37		OPTION PCB	1
38		BATTERY	1
39		PS PCB	1
40		BATTERY TERMINAL	2
41		AC INLET	1
42		AC ADAPTER	1
43		CAL PCB	1
44		BAR LCD	1
45		SEG LCD	1
46		BAR BACKLIGHT	1
47		SEG BACKLIGHT	1




## 14 Circuit diagram


### 1PZ4335 Circuit diagram




1PZ4336 Circuit diagram




1PZ4337 Circuit diagram



1PZ4840 Circuit diagram




1PZ4841 Circuit diagram






## 15 Parts layout and parts list


### 1PZ4335(1/2) Parts layout




1PZ4335(2/2) Parts layout




1PZ4336 Parts layout




1PZ4337 Parts layout



1PZ4840 Parts layout



1PZ4841 Parts layout



Symbol	Parts Name	Parts No.	Qty
	PCB	1PC4335F	1
U1	uCPU	1UCMN101CF57DAF	1
U2,4,6	ANALOG SWITCH	1UC4066F	3
U3	OP-AMP	1UAC4572G	1
U5,7	OP-AMP	1UAOP07CS8	2
U8	OP-AMP	1UAC358G2	1
U9	OP-AMP	1UAC4558G2	1
U10	VOLTAGE DETECTOR 4V	1UCS-80840ANNP	1
U11	NOR GATE	1UCHC02F	1
U12	FLIP-FLOP	1UCHC74F	1
U13	EEPROM 16K	1UC93C86	1
U14,15	REGULATOR 5V	1URTAR5S50	2
Q1,3,6,9,11,14,17,18	TRANSISTOR	1QTC2712Y-C	8
Q12,13	TRANSISTOR	1QTC2982B	2
Q15	TRANSISTOR	1QTA1242Y	1
Q16	TRANSISTOR	1QTA1162Y-C	1
D1	DIODE	1DI1SS226-C	1
D11~20,27	DIODE	1DI1SS184-C	11
D21~23	DIODE	1DIMA2H735	3
D28	DIODE	1DI1SS181-C	1
D29	DIODE	1DZRD6.8MB2-C	1
BZ1	BUZZER	1ETKBS-20DB-4P0	1
LCD1	LCD (WEIGHT)	1EDBSJ061	1
LCD2	LCD (BAR)	1EDBRJ058	1
	BACK LIGHT (WEIGHT)	1EDBDJ057	1
	BACK LIGHT (BAR)	1EDBDJ056	1
D3	LED YELLOW (HI)	1DLUY5366X	1
D6	LED GREEN (OK)	1DLUG5304X	1
D9	LED RED (LO)	1DLUR5366X	1
X1	CERAMIC RESONATOR 20MHz	1XTEFJC2005E5B	1
NF1~5	EMI FILTER	1NFEXCEMT102BC	5
J1	CONNECTOR (FLASH)	1JI08P-S2T2-EF	1
J2	CONNECTOR (OPTION)	1JI10P-S2T2-EF	1
J3	DC-JACK	1EJ0470-01-230	1
J4	CONNECTOR (L/C)	1JI7P-S2T2-EF	1
J5	CONNECTOR (CAL)	1JI2P-S2T2-EF	1
S1~16	SWITCH	1SKEVQ21405R	16
C1,2,3,10,12,33,37,39~41, 45,46,50,55,71~73	CAPACITOR (CERAMIC) 0.1u	1CC0.1U25V-C	17
C5,24~30,35,36,38,42,43, 47,48,51,54,59,76	CAPACITOR (CERAMIC) 0.01u	1CC0.01U-C	19
C8,9	CAPACITOR (CERAMIC) 3P	1CC3P-C	2
C11,13,15,18,20,64~69	CAPACITOR (CERAMIC) 100P	1CC100P-C	11
C14,16,17	CAPACITOR (POLYPROPYLENE) 0.022u	1CPECWF2224JB	3

C19,21	CAPACITOR (POLYPROPYLENE) 0.0022u	1CPP1H223JZT	2
C23,44,49,58	CAPACITOR (TANTALUM) 4.7u	1CT1A4R7-C	4
C53,56	CAPACITOR (TANTALUM) 1u	1CT1V010-C	2
C60	CAPACITOR (ALUMINUM) 100u/35V	1CKSME35VB100	1
C63	CAPACITOR (CERAMIC) 47P	1CC47P-C	1
C75	CAPACITOR (CERAMIC) 22P	1CC22P-C	1
R1,4	RESISTOR (39K 1%)	1RC1/10W3902F	2
R2,3,5,6,8~11,13,14,26, 35,86,91~97,107	RESISTOR (100 5%)	1RC1/10W101J	21
R7,18,28,37,44,46	RESISTOR (220 5%)	1RC1/10W221J	6
R15	RESISTOR (22K 1%)	1RC1/10W2202F	1
R16	RESISTOR (9.1K 1%)	1RC1/10W9101F	1
R17,58,61,62,105,106	RESISTOR (10 5%)	1RC1/10W100J	6
R20,53,55~57,60,67~70, 75~79,98,102,108~111	RESISTOR (47K 5%)	1RC1/10W473J	21
R21	RESISTOR (18K 5%)	1RC1/10W183J	1
R50	RESISTOR (100K 1%)	1RC1/10W1003F	1
R51	RESISTOR (15K 1%)	1RC1/10W1502F	1
R52	RESISTOR (150K 1%)	1RC1/10W1503F	1
R54	RESISTOR (1K 5%)	1RC1/10W102J	1
R59	RESISTOR (15 5%)	1RC1/10W150J	1
R63,80,81,103	RESISTOR (4.7K 5%)	1RC1/10W472J	4
R64~66	RESISTOR (11K 1%)	1RC1/10W1102F	3
R71,72,84,99	RESISTOR (10K 5%)	1RC1/10W103J	4
R83	RESISTOR (1 5%)	1RC1/2W1R0J	1
R104	RESISTOR (120 5%)	1RC1/10W121J	1
RA1	RESISTOR (24.5K/1K/24.5K)	1RFRR282	1
RA2,3	RESISTOR (100K/100K)	1RFRR248	2
RA4,7	RESISTOR (44K/66K)	1RFRR284	2
RA5	RESISTOR (12K/10K/11K)	1RFRR286	1
RA6	RESISTOR (100/10K)	1RFRR285	1
	CORE (L/C)(ADAPTER)	1LRDF-R-25A-M-A	2
BAT+	CABLE (RED)	1KO2882-1	1
BAT-	CABLE (BLACK)	1KO2882-2	1
GND	CABLE (EARTH)	1KO2436-035	1
CAL	CABLE(CAL)	1KO964-02S040	1
FS1	FUSE(2A)	1FSCCP2E20	1
	SHIELD CASE (UP)	1044005255	1
	SHIELD CASE (DOWN)	1043004953	1

## 1PZ4336

Symbol	Parts Name	Parts No.	Qty
FS1	FUSE	1FSEAWK-315MA	1
	FUSE HOLDER	1FHD504-ADK	2
L1	INDUCTOR	1LLSU9V-02080	1
C1,2,4	CAPACITOR (CERAMIC)	1CC0.001U2KV	3
C3	CAPACITOR (FILM)	1CME2A104MW	1
J1	CONNECTOR	1JTLW1143-03ADK	1
T1	PCB TERMINAL	1TMF4050AS	1
	PCB	1PC4336C	1
N	CABLE (N)	1KB1-020007BU44	1
L	CABLE (L)	1KB1-020005BN44	1
E	CABLE (E)	1KO2436-008	1

## 1PZ4337

Symbol	Parts Name	Parts No.	Qty
	PCB	1PC4337	1
CAL	SWITCH	1SKSKHHAK	1

## 1PZ4840


Symbol	Parts Name	Parts No.	Qty
	PCB	1PC4840A	1
R1~5	RESISTOR (100 5%)	1RC1/10W101J	5
R6~8	RESISTOR (56K 5%)	1RC1/10W563J	3
R9~11	RESISTOR (560 5%)	1RC1/10W561J	3
C1~5	CAPACITOR (CERAMIC) 1u/50V	1CC1U50V-C	5
U1	RS232C DRIVE IC	1UCMAX232CWE	1
U2~4	PHOTO MOS RELAY	1DFAQV253HA	3
J1	CONNECTOR	1JI10P-S2T2-EF	1
J4	TERMINAL (6P)	1TMMKDSN1.5/6	1
J5	TERMINAL (4P)	1TMMKDSN1.5/4	1
L1	CORE	1LRBFR120507ADK	1
Q1~3	TRANSISTOR	1QTC2712Y-C	3
1	CABLE (BROWN)	1KB1-030011BN44	1
2	CABLE (RED)	1KB1-030011RD44	1
3	CABLE (ORANGE)	1KB1-030011OG44	1
4	CABLE (YELLOW)	1KB1-030011YW44	1
5	CABLE (BLACK)	1KB1-030011BK44	1

Symbol	Parts Name	Parts No.	Qty
	PCB	1PC4841B	1
R1~5,12,13	RESISTOR (100 5%)	1RC1/10W101J	7
R6~8,15	RESISTOR (56K 5%)	1RC1/10W563J	4
R9~11	RESISTOR (560 5%)	1RC1/10W561J	3
R14	RESISTOR (100 5%)	1RC1/2W101J	1
R16	RESISTOR (12K 5%)	1RC1/10W123J	1
R17	RESISTOR (3.3K 5%)	1RC1/10W332J	1
C1,2,11	CAPACITOR (ALUMINUM) 100u/16V	1CKSME16VB100	3
C3,4,10	CAPACITOR (CERAMIC) 1u/50V	1CC1U50V-C	3
C5,6	CAPACITOR (TANTALUM) 4.7u	1CT1A4R7-C	2
C7~9	CAPACITOR (CERAMIC) 0.1u/25V	1CC0.1U25V-C	3
U1,5	TRANSCEIVER	1UCLTC1484CS8	2
U2~4	PHOTO MOS RELAY	1DFAQV253HA	3
U6	REGULATOR 5V	1UR24M05HF	1
U7	NAND GATE	1UCHC08F	1
Q1~4	TRANSISTOR	1QTC2712Y-C	4
Q5	TRANSISTOR	1QTA1242Y	1
D1,2	DIODE	1DZRD6.2Z-C	2
J1	CONNECTOR	1JI10P-S2T2-EF	1
J4,5	TERMINAL (6P)	1TMMKDSN1.5/6	2
L1	CORE	1LRBF120507ADK	1
	PAN HEAD SEMS M3x10	11701SX-N3X10	1
	HEX NUT M3	11703-11-SX3	1
	WASHER M3	11704-21-BN3	1
1	CABLE (BROWN)	1KB1-030011BN44	1
2	CABLE (RED)	1KB1-030011RD44	1
3	CABLE (ORANGE)	1KB1-030011OG44	1
4	CABLE (YELLOW)	1KB1-030011YW44	1
5,6	CABLE (BLACK)	1KB1-030011BK44	2

Symbol	Parts Name	Parts No.	Qty
	AC OUTLET	1JSDCZ-01	1
	AC ADAPTER	1TB230	1
	AC CABLE (A PLUG)	1KO3008	1
	AC CABLE (C PLUG)	1KO3009	(1)
	AC CABLE (BF PLUG)	1KO3010	(1)
	AC CABLE (S PLUG)	1KO3011	(1)
	EARTH WASHER	1044020208	1
	EARTH CABLE (CASE)	1KO2561-013O3O3	1
	EARTH CABLE (OPTION)	1KO2561-025O3B7	1
	CABLE THAILAND BASE	110DAMB10	1
	PAN HEAD W-SEMS M3x8	11702FN-S3×8	1



## 16 Wiring Diagram






## 17 Specifications


MODEL		FS-6Ki	FS-15Ki	FS-30Ki
kg	Capacity	6	15	30
	Min. display	0.002*	0.005*	0.01*
		0.001	0.002	0.005
		0.0005	0.001	0.002
g	Capacity	6000	15000	30000
	Min. display	2*	5*	10*
		1	2	5
		0.5	1	2
lb	Capacity	15	35	70
	Min. display	0.005*	0.01*	0.02*
		0.002	0.005	0.01
		0.001	0.002	0.005
oz	Capacity	240	560	1120
	Min. display	0.1*	0.2*	0.5*
		0.05	0.1	0.2
		0.02	0.05	0.1
lb-oz	Capacity	15	35	70
	Min. display	0.1	0.1	0.1
Repeatability (Std. Deviation)		0.001kg	0.002kg	0.005kg
Linearity error		±0.002kg	±0.005kg	±0.01kg
Span drift		±20 ppm / °C (5°C~35°C)		
Display		7 segment LCD display (Character height 18.6 mm) with backlight 60 segment analog sweep display with backlight		
Display update		Approximately 20 times per second		
Operating temp.		-10°C~40°C / 14°F~104°F, Less than 85% R.H.		
Power supply		AC main (100V~240V) or SLA battery (option)		
Weighing pan size		250×250 mm		380×300 mm
Dimension		250(W)×414(D)×496(H) mm 9.8(W) X 16.3(D) X 19.5(H) in.		380(W)×464(D) ×496(H) mm 15.0(W) X 18.3(D) X 19.5(H) in.
Weight (apporoximately)		8.1lg		14.9kg
Calibration weight		6kg 15lb	15kg 30lb	30kg 60lb

\*) Factory setting

FS-6Ki  
FS-15Ki



FS-30Ki



Unit: mm





**A&D Company, Limited**

3-23-14 Higashi-Ikebukuro, Toshima-ku, Tokyo 170-0013 JAPAN  
Telephone: [81] (3) 5391-6132 Fax: [81] (3) 5391-6148